



063-UWB-0316



Cert No. 5661/02



Flanged Swing Check Valve Fig. 302

General Description

Rapidrop Fig. 302 is a rubber faced, flanged swing type check valve that allows water flow in one direction only. A hinged clapper remains open with water flowing in one direction, and automatically closes when flow stops preventing back flow. Removable cover allows easy access for inspection and maintenance. These valves are suitable for installation in both horizontal and vertical (with the flow upwards) pipelines. Rapidrop Fig. 302 flanged swing check valve is only available with ANSI 125/150 flanges.

Applications

Potable water, sewage disposal, water distribution service & feed lines, irrigation and fire protection pipe systems

Connections

ANSI 125/150 Flange to ASME B16.1

Maximum Working Pressure

20.7 bar (300 psi) FM Approved

20.7 bar (300 psi) UL Listed

25.0 bar (362 psi) LPCB & CNBOP Certificates

Temperature Range

0°C to 80°C (32°F to 176°F)

Coating

Fusion Bonded Epoxy Coating

In accordance with ANSI / AWWA C550

Approvals

FM Approved

UL Listed


LPCB Certificate

CNBOP Certificate

WRAS Approved product

Installation

The valve must be installed with the direction arrow on the body in line with the direction of the flow in the pipeline. Rapidrop swing check valves can be installed horizontally or vertically. For vertical pipe work the flow direction should be upwards only. When installed horizontally the cover must be facing up. Large valves are provided with lifting eye bolt, which should be used to manoeuvre the valve.



Dimensions

Size		Dimensions (mm)		Weight (Kg)	Product Ordering Code
mm	inch	L	H		
DN 50	2"	203	133	11.2	RD302CV050A
DN 65	2 1/2"	254	150	16.7	RD302CV065A
DN 80	3"	278	160	22.5	RD302CV080A
DN 100	4"	330	218	34.9	RD302CV100A
DN 150	6"	406	290	65.2	RD302CV150A
DN 200	8"	495	330	120.7	RD302CV200A
DN 250	10"	622	350	180.9	RD302CV250A
DN 300	12"	660	376	242.3	RD302CV300A

Flanged Swing Check Valve

Fig. 302

Maintenance

1. Notify any authority having jurisdiction and all personnel who may be affected prior to commencing inspection.
2. Close water supply, isolate and completely drain the valve.
3. Unscrew the bolts (3) and remove the cover (2).
4. Inspect internal parts, ensure correct operation and replace damaged parts.

- a. Seat ring (7)
- b. Cover and cover O-ring (2&6)
- c. Clapper assembly, gasket and hinge pin (8-14)

Change the clapper gasket:

- i. Remove the clapper assembly from the valve body

Unscrew one of the hinge plugs (16) from the valve body (1) and carefully remove the hinge pin (8), both hinge bushes (9) and the clapper assembly (10-14) from the valve body.

- ii. Change the clapper gasket if necessary

Remove the nut (14), the spring washer (13) and the retaining disk (12)

Replace the gasket (11) with a new one.

Reassemble in reverse order.

- iii. Reinstall clapper assembly


Insert the bushes (9) in the slots of the clapper arm (10) and carefully position the assembly inside the valve body (1) with the clapper gasket (11) facing the opposite direction of the flow arrow.

Line up the holes of the hinge plug (16) and the valve body (1) and insert the hinge pin (8).

Screw the hinge plug (16) into the valve body (1).

Ensure that the clapper assembly (10-14) moves freely.

5. Make sure all jointing faces are clean.
6. Carefully position cover ensuring O-ring (6) is not displaced.
7. Refit bolts (3) and tighten evenly.



Material Specification

No	Description	Material
1	Valve Body	Ductile Iron 65-45-12
2	Cover	Ductile Iron 65-45-12
3	Bolt	Carbon Steel Zinc Plated
4	Washer	Carbon Steel Zinc Plated
5	Eye Bolt *	Carbon Steel Zinc Plated
6	O-ring	NBR /EPDM
7	Seat Ring	Bronze C83600
8	Hinge Pin	SS304
9	Hinge Bushing	Brass C36000
10	Clapper Arm	Ductile Iron 65-45-12
11	Clapper Gasket	EPDM
12	Retaining Disc	Ductile Iron 65-45-12
13	Spring Washer	SS316
14	Nut	SS316
15	Washer	Nylon
16	Hinge Plug	Carbon Steel Zinc Plated
17	Drain Plug	Copper Alloy
18	Stud	SS316

*DN100 /4" and above

Important Installation Information

- *Rapidrop Figure 302 swing check valve* must only be installed by a competent person in accordance with requirements of the local authority having jurisdiction. Deviations from these standards will invalidate warranty.
- It is the responsibility of the installing contractor to include a copy of this document in the sprinkler system installation, operating and maintenance manual.
- Alterations to Rapidrop products will void any warranty.
- *Figure 302 swing check valve* should be inspected and maintained during routine sprinkler system inspections by a competent person in accordance with national codes/requirements.
- Failure to follow these instructions could cause improper operation, resulting in personal injury and/or property damage.
- For further details and technical support please contact your Rapidrop sales representative.