



Pressure Relief Valve Fig.55L-60

Product Description

The 55L-60 Pressure Relief Control is a direct acting, spring loaded, diaphragm type relief valve. It may be used as a self-contained valve or as a pilot control valve. It opens and closes within very close pressure limits.

Installation

The 55L-60 Pressure Relief Control may be installed in any position. The control body (1) has one inlet and one outlet port. Body (1) also has smaller side ports; one on inlet, one on outlet, each with pipe plugs (23) installed. These smaller side ports are used for control connections or gauge applications. The body (1) also has one center side port, used as the sensing line port. A flow arrow is marked on the body casting.

Operation

The 55L-60 Pressure Relief Control is normally held closed by the force of the compression spring above the diaphragm; control pressure is applied under the diaphragm. When the controlling pressure exceeds the spring setting, the disc is lifted off its seat, permitting flow through the control. When controlling pressure drops below spring setting, the spring returns the control to its normally closed position.

Adjustment Procedure

The 55L-60 Pressure Relief Control can be adjusted to provide a relief setting at any point within the range found on the nameplate.

Pressure adjustment is made by turning the adjustment screw (11) to vary the spring pressure on the diaphragm. Turning the adjustment screw clockwise increases the pressure required to open the valve. Counterclockwise decreases the pressure required to open the valve.

When pressure adjustments are complete the jam nut (10) should be tightened and the protective cap (12) replaced. If there is a problem of tampering, lock wire holes have been provided in cap and cover. Wire the cap to cover and secure with lead seal.

Inspection

Inspect all parts for damage, or evidence of cross threading. Check diaphragm for tears. Check stem assembly (4) for abrasions or other damage. Check all metal parts for damage, corrosion or excessive wear.

Repair and Replacement

Minor nicks and scratches may be polished out using 400 grit wet or dry sandpaper fine emery or crocus cloth. Replace all O-rings and any damaged parts. When ordering replacement parts, be sure to specify parts list item number and all nameplate data.

Disassembly

The 55L-60 Pressure Relief Control does not need to be removed from the line for disassembly. Make sure that pressure shut down is accompanied prior to disassembly. If the 55L-60 is removed from the line for disassembly be sure to use a soft jawed vise to hold body during work.



1. Remove cap (12), loosen jam nut (10) and turn adjusting screw counterclockwise until spring tension is relieved.
2. Remove the eight screws (15) holding the cover (9). Keep the cover and eight screws together and place on a suitable work surface. See NOTE under REASSEMBLY.
3. Remove the cover (9) from body (1). The spring (8) and two spring guides (7).
4. Remove plug (22) from body (1). Using screwdriver, hold stem assembly (4) to remove nut (13).
5. Slide off the belleville washer (14), upper diaphragm washer (18), diaphragm (17) and lower diaphragm washer (19).
6. Remove stem guide (21) from body (1). Remove stem assembly (4). Inspect, replace stem assembly and/or O-rings (5), (6) and (20) if necessary. Use soft jawed pliers or vise to hold stem. The polished surface of stem must not be scored or scratched.
7. The seat (3) need not be removed unless it is damaged. If removal is necessary use proper size socket wrench and turn counterclockwise.

Reassembly

In general, reassembly is the reverse of disassembly. However, the following steps should be observed:

1. Lubricate the O-Ring (5) and (6) with a small amount of a good grade of waterproof grease, (Dow Corning 44 medium grade or equal). Use grease sparingly when installing O-ring (20) into guide stem (21).
2. Install stem assembly (4) into guide stem (21). Use a rotating motion with minimum pressure to let stem pass through O-ring. Do Not Cut O-Ring.
3. Install O-ring (6) at top of stem assembly (4). Install guide stem (21) and stem assembly (4) into body (1). Use socket to tighten securely. Place lower diaphragm washer (19) on the stem assembly with the serrated side up. Position diaphragm (17), upper diaphragm washer (18), with serration down, and belleville washer (14) with concave side down.
4. Install nut (13) and tighten securely .
5. Continue reassembly as outlined in disassembly steps 1 through 3.

Pressure Relief Valve Fig.55L-60



Troubleshooting

Symptom	Probable Cause	Remedy
Fails to open	Controlling pressure too low	Back off adjusting screw until valve opens
Fails to open with spring compression	Mechanical obstruction, corrosion or scale build up on stem	Disassemble, locate and remove obstruction or scale
Leakage from cover vent hole when controlling pressure is applied	Diaphragm damage	Disassemble, replace damaged diaphragm
	Loose diaphragm assembly	Tighten upper diaphragm washer
Fails to close	No spring compression	Re-set pressure adjustment
Fails to close with spring compression	Mechanical obstruction	Disassemble, locate and remove obstruction

Parts

Item No	Description
1	Body
2*	O-Ring
3	Seat 1/2" & 3/4"
4*	Stem Assembly
5*	O-Ring
6*	O-Ring
7	Guide Spring
8	Spring
9	Cover
10	Hexnut
11	Adjusting Screw
12	Cap
13	Nut, Stem
14	Flat Washer
15	Fil HD Screw
16	Nameplate
17*	Diaphragm
18	Washer Diaphragm Upper
19	Diaphragm Washer
20*	O-Ring
21	Guide Stem
22	3/4" NPT Pipe Plug
23	1/8" NPT Pipe Plug
24	Drive Screw

*Suggested repair parts

Manufactured by CLA-VAL who hold UL Listing and FM Approval.